



# Tiger Decor Texture Render

Premium product of  SCG





# TIGER DECOR Texture Render (Textured Surface Colored Plastering)



## Product Name for SPEC

**TIGER DECOR**  
**Texture Render**  
Color Code/Plastering Condition

Color Code As Specified in Catalogue

Example:

**TIGER Decor Textured Surface Colored  
Plastering**

(Texture Render) YE01/Scratch

## Quality Certification



• ISO 9001 : 2008 QMS 01185/436

ISO 9001



• ISO 14001 : 2004 : EMS 01025/063

ISO 14001

- Water Retention ASTM C91-95C
- Compressive strength ASTM C109/C109M-95
- Air Content ASTM C185-95
- Time of Setting astm c807-89
- Bonding Strength ASTM C952
- Durability with Weathering accelerator
- ASTM G151, ASTM G154, ASTM D4587

## Product Details

- Color Texture Render suitable for final layer decorative plastering
- Package size 20 kg/package

## General Properties

- Contains special substance that helps increase water absorption capacity and reduce brittleness
- Contains air bubbles increasing agent for easier plastering
- Contains special adhesive agent to increase adhesiveness between the surface and the tiles
- Contains special agent to prolong drying time to allow for more flexibility and appropriate setting time
- Contains anti-white stains agent that can help increase durability for longer usage

## Usage

- Leave the wall to dry; make sure that there is a little humidity left as possible. Generally, the wall should be left to dry for at least 2 weeks.
- Clean the wall thoroughly; make sure there is no dust, dirt or anything on the smooth surface with dry sponge, broom or sandpaper. Clean oily surfaces, if any, with soap water, dishwashing agent or shampoo. Leave the wall until well dry.
- Apply contact primer thoroughly; twice. Leave to dry. This will help make sure that the Tiger Decor Color Render, once applied, is smoothed out for the entire area. It also helps prevent water seeping through the wall, reducing alkalinity and increasing overall adhesiveness.
- Use metal trowel to put and press the texture render onto the wall. Smooth out the application.  
**\*For Scratch Application, apply the mixed texture render and smooth it out immediately**  
**\*For Worm Application, apply the mixed texture render and leave it on the wall for approximately 20 minutes before smoothing the mixture out**
- Leave to dry to reduce humidity inside the wall for 1 - 2 days. Apply 2 layers of coating agent. The second coating should be done when the first coating is still moist. Otherwise, if the wall is too dry, the second layer of coating will not permeate the wall and that may lessen the overall quality of coating.
- Leave to dry.

**Note: Check for properly done coating application by pouring water onto the wall when the coating agent is already dry. If the water remains in droplets (Lotus Effect) that means the coating is complete and properly done. (If, however, the wall becomes wet immediately after the water is splashed on the wall that means the coating is not complete or properly done).**

## Total Area (Sq.M. / Package)

- For 1 mm thickness, a total area of approx. 10-14 sq.m. can be covered.
- For 2 mm thickness, a total area of approx. 5-7 sq.m. can be covered.


## Suggestions

- For color uniformity, always use primer before applying the color skim coat onto the wall. The skim coat should, however, be applied after primer is used for one day.
- For ease of use, mixing tools such as electronic mixer may be used.
- Do not add water to the mixture after first use.
- The texture render is intended for the final layer decorative plastering only. Do not lather.
- For durability, use waterproof coating agent for outdoor project.


## Cautions

- Touching or inhaling ready-mix concrete powder or wet concrete mixture may cause allergic reactions, skin irritation, or irritation in the respiratory tract.
- If the concrete powder comes into contact with eyes, it may cause extreme irritation and can be extremely dangerous.
- This product is not for consumption. Do not eat.
- Proper working temperature should be between 15 - 40 degrees Celsius.
- Avoid working outdoors and under strong sunlight or strong wind. If necessary, however, the installer must do so with appropriate shelter.
- Do not mix with any other additional materials. If necessary, consult directly with the manufacturer of the products first.
- For painted wall, wash the area thoroughly first before applying primer to help prevent brittleness.
- For Smartboard/Visa Board/ Gypsum Board, primer application is necessary because these walls have very little adhesiveness.

## SCRATCH 1 mm



## WORM 2 mm.



Note: Actual colors may vary from the colors represented here due to printing.